

Installing Dye Black Film Ink Cartridges

A quick-start guide for Dye Black Film Ink Cartridges

Unpackage your cartridges and remove the yellow pull tabs.

Each cartridge is labeled for its proper slot. Insert the cartridges in your printer matching each cartridge to its slot (you cannot use cartridges designed for a particular slot in any other slot as this can damage the cartridge chip and will not function properly).

Make sure the cartridges all comfortably fit and make a slight clicking sound indicating they have each made the proper contact.

In rare instances a cartridge does not set or fails due to static electricity or a power surge. The chip simply needs reprogramming which is easily accomplished using the [chip resetter](#) [1].

You will now need to turn on the black ink option in [AccuRIP Software](#) [2] (or verify the setting is still on from previous use). Under AccuRIP's FILE MENU>Setup simply CLICK the Multi-black option. You will see that your entire list of cartridge slots are checked and ON. Note: you have the ability to check on or off any or all slots. Make sure you manage this section properly to avoid uneven draining of cartridges.

Source URL: <http://buyarip.com/support/installing-dye-black-film-ink-cartridges>

Links:

[1] <http://buyarip.com/chip-resetter>

[2] <http://buyarip.com/accurip>