


AccuRIP Printer Dimension Accuracy Test



Instructions:

1. Print this scale to the same film (media) you will use to make your positives or negatives.
2. Measure this scale with an accurate ruler.
3. Use the "Adjust Print Length" in the Setup window of AccuRip to adjust the Inkjet Printer for perfect printing.
4. Positive numbers increase the length of your print while negative numbers decrease the length.
5. Use the numbers (+19 or -19) as a starting point. Changes in increments of 5 create visual changes. (The distance these numbers effect vary with media and printer).

Why you need this:

1. Most wide format printers experience a small amount of distortion due to the varied "thickness" of film media as they effect roller speeds, as well as atmospheric changes such as humidity and heat.
2. Due to new inkjet printer feed features and roller wear this ability is more important than ever.
3. Screen Printers that need to match films to die cut templates and "nesting" (N-UP) multi color separations need exact dimension control can lengthen and shorten their prints as needed. using the "Length Adjustment" option located in the SETUP window of AccuRIP.